



Basket Press

Equipment Check List: **Please check that you have everything**

Mill:

1. Milling machine, with curved screen and on line RCD)
2. Hopper
3. Two hopper securing bolts (NB extended bolt goes on RHS for microswitch)
4. 13mm Spanner

Press:

1. Metal Press
2. Stainless steel tray
3. Wooden basket
4. Net Bag (to hold pulp within basket)
5. Wooden pressing disc (with metal handles)
6. Wood pressing block
7. Metal turning bar
8. Metal bolt/pawl (pin which fits into the press's turning head)

Pasteuriser:

1. Pasteuriser
2. Thermometer

Accessories:

1. Three flexible buckets (for washing apples, collecting pulp etc)
2. One bucket (to collect juice with)
3. One sieving bucket
4. One laminated Equipment List / Instructions card

Cleaning after use:

Mill: After use, disconnect from the mains power supply, remove hopper and wash all parts of the mill (excluding motor) with fresh water before the sticky pulp dries. Ensure that no water is splashed onto the motor during this operation.

For ease of transport screw bolts back into sockets but leave hopper separate

Press: After use, wash all parts of the press with fresh water before the sticky apple juice and pulp dries. The cloth is machine washable at 40C but drip dry, do not spin. The wooden basket etc should be scrubbed clean and allowed to dry before storage. Damp wood goes mouldy.

Pasteuriser: After use, wash the inside with warm fresh water; keep water well clear of the electrics!

Buckets etc: Wash all out with fresh water.